


The Builder is to check and verify all building and site dimensions, levels and sewer invert levels prior to commencement of work. do not scale off this drawing, work to figured dimensions only.  
 This drawing must be read and checked with all structural and relevant specialist drawings.  
 The builder is to comply in all aspects with the current Building Regulations and latest codes of practice.  
 Ordnance Survey Ltd paper mapping licence / customer account number 100060636.



Location plan.

Scale 1:1250

1:1250

25m 0 25m 50m 75m 100m 125m

